

Grizzly "CUB" Rider Handguards

Installation Instructions



Polaris AXYS/Matryx RMK Installation

1. Insert the strap end through the slot in the hand grip as shown. Pull it up to the plastic and insert the plastic into the slot and pull it fully until it stops. Next, route the strap through the slider as shown and pull it back on itself and hook with the velcro.



Note:

If you are using the OEM brake lever, you may need to adjust the lever in slightly to prevent the lever from hitting the handguard. We recommend a Skinz/Burandt adjustable heated or non-heated lever as an option.



2. Your handguards include the urethane gripper as shown. Make sure it is positioned in the velcro close to the slider end as shown. This will make it so you can tighten it down completely. If there is too large a gap between the slider and the end of the urethane gripper, you will not be able to cinch it down as tightly as needed. Place the gripper around the bars in a location that Does Not affect the throttle cable or inhibit any necessary action of wires or cables. Route the strap end through the slider and tighten, attaching the loop velcro to the hook velcro as shown.



For Technical Info:
Info@skinzprotectivegear.com

Grizzly Guard Mount Kit

(All units except for Polaris RMK)

1. Install mounts as shown in pictures below. Note: Be careful tightening the half mounts. All grips are different diameters so only tighten enough to secure from movement. Also, If you are installing on a bar that has turn downs or hooks, install the slotted blocks as shown. If you are installing on a straight bar, flip the mounts and install.



2. Once you have the mounts installed, you can use the slot to install the strap/tab just like the Polaris hook.
See pictures below.



For Technical Info:
Info@skinzprotectivegear.com